


Exploded View for BD6000



Part List for BD6000

No.	symbol		QTY
1	B170.0-1	Guardrail	1
2	B170.0-2	Chrome Beer Tower	1
3		Tapping Screw	3
4	B170.0-3	Spanner	1
5	B170.1	Cabinet Urethane Assembly	1
6	B170.0-4	Water Collection Reservoir	1
7	B170.0-5	Fastener-1	1
8	B170.0-6	Fastener-2	1
9	B170.2	Door Assembly	1
10	B170.2-2	Door Gasket	1
11	B170.2-1	Door Liner	1
12		Tapping Screw	24
13	B110.4	Top Hinge	1
14	B170.0-9	Thermostat	1
15		Tapping Screw	2
16	B102.0-2	Thermostat Enclosure	1
17	B102	Thermostat Knob	1
18	B170.0-7	Evaporator	1
19		Tapping Screw	4
20	B170.0-12	Hoses	1
21	B170.0-11	Valve	1
22	B170.0-10	Beer Pot	1
23	B170.0-8	Shelves	2
24	B170.0-13	Beer Pot Bracket	1
25	B170.0-14	Bracket Base	1
26	B151.2.9	Bottom Hinge	1
27	B170.0-19	Idler wheel	4
28		Screw	16
29	B170.0-17	Guardrail Insert	1
30	B170.0-16	CO ₂ Tank	1
31	B170.0-15	CO ₂ Tankholder	1
32	B103.0-2	Botton	4
33	B170.0-18	Compressor Base	1
34		Fixed Bolt	4
35	B102.1	Power Supply Cord	1
36	B143.0-18	Drier	1
37	B107.0-2	Relay Cover	1
38		Tapping Screw	2
39		Grommet	1
40		Bushing	1
41		Bolt	4
42	B170.0-20/0	Compressor	1
43	B170.0-20/1	Over Load Protector	1
44	B170.0-20/2	PTC Starter	1
45	B170.0-20/3	Wire Cover	1
46	B170.0-20/4	Relay Band	1