



ER2002CSS

No.	Name	Qty.	Factory part code	No.	Name	Qty.	Factory Part code
1	Backplate of Backsplash	1	TO62CY00002	48	Pad of glass	4	
2	Backsplash	1		49	Door Upper Insulation	1	
3	Positioning Bolt	2	TY-BZJ00135	50	Middle Inner Glass	1	
4	Rear Oven Insulation	1		51	Door glass	1	TO62SL00009
5	Oven Enclosure Insulation	1		52	Handle connection piece	4	TO62FW00031
6	Right Console	1		53	Door handle	1	
7	Left Console	1		54	Door Lower Strip	1	
8	Lamp Holder	1		55	Door side insulation	2	
9	Lamp	1		56	Right Side Support	1	Z-E62A-46-2(T) / TO62CY00015
10	Lamp Cover	1		57	Drawer Handle	1	
11	Funnel	1		58	Drawer Panel	1	TO62FW00056
12	Thermostat Clamp	1	Z-E62A-40(T) / TO62CY00059	59	Drawer board	1	TO62FW00013
13	Bake Heater Bracket	1		60	Drawer bracket	1	TO62CY00001
14	After the board liner	1	TO62FW00021	61	Drawer body	1	TO62FW00011
15	Under the board liner	1	TO62FW00025	62	Drawer support left position	1	TO62CY00032
16	Roof Liner	1	TO62FW00022	63	Positioning the right drawer bracket	1	TO62CY00033
17	Splash Tray	1	TO62FW00008	64	Right drawer slide	1	TO62SL00002
18	Location column	2		65	Drawer slide left	1	TO62SL00001
19	Metal Clip	4	Z-E62A-38(T) / TO62CY00008	66	Door seal	1	TO62SL00005 / Z-E62A-78(T)
20	Burner Connector	4	Z-E62A-80(T) / TO62SL00033	67	Door seal hook	4	TO62CY00017
21	Cook Top	1	TO62CY00043 / Z-ER2002CSS-CT	68	Connecting piece door seal	1	TO62CY00018
22	8" Reflector Bowl	1	TO62FW00146 / Z-ER2002CSS-8RB	69	Inner front panel	1	TO62FW00020
23	6" Reflector Bowl	3	TO62FW00145 / Z-ER2002CSS-6RB	70	Door hinge mounting plate	2	
24	8" Burner	1	E62A.61(T) / TO62DQ00004	71	Drawer slide plate	1	TO62CY00006
25	6" Burner	3	E62A.62(T) / TO62DQ00003	72	Drawer slide	2	TO62SL00003
26	Support Bar	1	TO62WJ00005	73	Bottom Bracket music code	1	TO62FW00017
27	Support hook clip	1	TO62CY00011	74	Adjustable feet	4	Z-E62A-84(T) / TO62SL00004
28	Liner Side	2		75	Bottom Bracket	1	TO62FW00016
29	Left Side panel	1	TO62FW00051	76	Under the bottom bracket angle	4	
30	Plate Hinge	2	Z-E62A-39(T) / TO62CY00058	77	Bottom bracket angle	4	
31	Plate Cushion	2	Z-E62A-86(T) / TO62SL00008	78	Drawer mounting plate	1	TO62CY00005
32	Left side panel trim	1	TO62FW00053	79	Partition Plate	1	TO62CY00007
33	Power Switch	4	E62A.58(T)	80	Bake Heater	1	TO62DQ00002 / Z-E62A.57(T)
34	Thermostat	1	Z-E62A.60(T) / TO62DQ00010	81	Broiler Heater	1	Z-E62A.56(T) / TO62DQ00001
35	Function Switch	1	Z-E62A.59(T) / TO62DQ00008	82	Anti-tip Bracket	2	Z-E62A-54(T) / TO62BC00013
36	Control Panel	1	TO62CY00044 / Z-ER2002CSS-CP	83	Right panel trim	1	TO62FW00054
37	Indicator Light Cover	1		84	Right side Plate	1	TO62FW00024
38	Knobs	6	Z-E62A-91(T) / TO62SL00010	85	Broiler Pan	1	Z-TO62FW00002
39	Inner Glass	1		86	Broiler Grid	1	TO62FW00003
40	Inner Glass Fixing Washer	2	Z-E62A-49(T) / TO62CY00016	87	Wire Rack	2	E62A.67(T) / TO62WJ00001
41	Inner Glass Gasket	1	TO62SL00006	88	Inner Back Plate	1	TO62CY00004
42	Door Upper Seal	1		89	Conduit Bracket	1	TO62CY00021
43	Door Frame	1	TO62FW00004 / Z-ER2002CSS-DF	90	Terminal	1	
44	Washer	2	Z-E62A-97(T) / TO62SL00015	91	Balance block	2	TYDQBJ00017
45	Fixing Base	2	Z-E62A-53(T) / TO62CY00020	92	Rear Cover	1	TO62CY00003
46	Door hinge (Male)	2	Z-E76A.74 / TO62WJ00008	93	Terminal Access Plate	1	TO62CY00012
47	Glass left side support	1	Z-E62A-46-1(T) / TO62CY00014				