


Parts Breakdown



Parts List

NO.	PART NAME	PART CODE	
		FF12Y	FF8Y
6-2	FREEZER DOOR GASKET ASS'Y	3012306901	3012306101
6-3	FREEZER TOP POCKET	3019009410	3019007810
6-4	FREEZER BOTTOM POCKET	3019009610	3019007810
7	REFRIGERATOR DOOR ASS'Y	PFRT00N035	PFRT00J065
7-1	REFRIGERATOR DOOR URETHANE ASS'Y	PFRU00N015	PFRU00J015
7-1-1	REFRIGERATOR TOP HANDLE BUSHING	4010Y36211	4010Y36211
7-1-2	REFRIGERATOR DOOR BUSHING	4010G38023	4010G38023
7-1-3	REFRIGERATOR DOOR STOPPER	4010G38034	4010G38034
7-1-4	SCREW TAPPING	7122401611	7122401611
7-2	REFRIGERATOR DOOR GASKET ASS'Y	3012307001	3012306001
7-3	EGG CONTAINER	3011115600	3011112200
7-4	REFRIGERATOR UTILITY POCKET (TOP)	3019009410	3019007810
7-5	REFRIGERATOR UTILITY POCKET (BOTTOM)	3019009410	3019007810
7-6	REFRIGERATOR BOTTLE RACK (TOP)	3019009310	3019007710
7-7	REFRIGERATOR BOTTLE RACK (BOTTOM)	3019009610	3019007910
8	ADJUSTABLE FOOT ASS'Y	3012101300	4001E32531
9	MIDDLE HINGE ASS'Y	3012906300	3012906300
10	SPECIAL BOLT	3016004000	3016004000
11	DOOR SWITCH ASS'Y	3011721300	3011721300
12	TOP HINGE ASS'Y	3012906500	3012906500
13	SPECIAL SCREW	3016000301	3016000301
14	TOP HINGE COVER	3011430100	3011430100
15	SPECIAL BOLT	3016002200	3016002200
16	ICE CUBE TRAY	4017Z99112	4017Z99112
17	ICE CUBE BOX	4010G56011	4010G56011
18	FREEZER SHELF	4010C55112	3017811000
19	CHILLED COMPARTMENT	3010100011	3011112011
20	CHILLED COMPARTMENT DOOR	3011721510	--
21	REFRIGERATOR SHELF	4010C55221	3017811100
22	VEGETABLE CRISPER COVER	3011424800	3011436201
23	VEGETABLE CRISPER	3011115500	3011119000
24	LAMP ASS'Y	3013600050	3013600050
25	WINDOW (R) OR SHADE (R)	3015503600	4017Z87570
26	COMPRESSOR EVAPORIZATION TRAY	3011161200	3011116102
27	GRILLE	3012400810	3012400310
28	TAPPING SCREW	7112401211	7112401211
29	POWER CORD ASS'Y (KP-30)	3011301712	3011301712

Parts List

NO.	PART NAME	PART CODE	
		FF12Y	FF8Y
1	CABINET URETHANE ASSEMBLY	PFCU00N015	PFCU00J015
1-1	EVAPORATOR SUB-ASS'Y	3017004720	3017002802
1-2	BI-METAL SWITCH ASS'Y	3018111810	3018111810
1-3	TEMP. FUSE ASS'Y	3017200650	3017200650
1-4	TEMP. FUSE FIXTURE	4017Z90590	4017Z90590
1-5	DEFROST HEATER TOP COVER	4017Z73570	4019R73570
1-6	DEFROST HEATER ASS'Y	3012804300	3012803700
1-7	DEFROST HEATER UPPER COVER	4017Z73580	4019R73580
1-8	UPPER HINGE ASS'Y	3012906701	3012906701
1-9	HEXAGON BOLT	7650602011	7650602011
2	COMPRESSOR BASE ASS'Y	--	--
2-1	COMPRESSOR BASE SUB-ASS'Y	3010302800	3010312610
2-2	COMPRESSOR ABSORBER	3010100201	3010100201
2-3	COMPRESSOR	3953118510	3953118510
2-4	SPECIAL WASHER	4019H09030	4019H09030
2-5	RELAY SWITCH ASS'Y	3018113613	3018113613
2-6	RELAY BAND	3816100100	3816100100
3	FREEZER MOTOR ASS'Y	3015900570	3015904060
3-1	FAN MOTOR COVER (B)	4017Z32250	4017Z32250
3-2	MOTOR ABSORBER	4017Z08430	4017Z08430
3-3	MOTOR SUB-ASS'Y	3015904270	3015900460
3-4	FAN MOTOR COVER (C)	4017Z32260	4017Z32260
3-5	FAN MOTOR COVER (A)	4017Z86430	4019H32240
3-6	FAN	4017Z42312	4019H10310
3-7	FAN RING FIXTURE	4019H10060	4019H10060
4	LOUVER ASS'Y	3018906100	3018906000
4-1	FREEZER INSULATION-LOUVER ASS'Y	3013327800	3013328000
4-2	FREEZER LOUVER KNOB	3013401000	3013401000
4-3	FREEZER LOUVER	3018905700	3018904900
5	MULTI-DUCT ASS'Y (R) OR CONTROL BOX ASS'Y	3016908750	3010517520
5-1	MULTI-DUCT (R) OR CONTROL BOX	3016907910	3010514310
5-2	THERMOSTAT	3018301300	3018301300
5-3	TAPPING SCREW	7121400811	7121400811
5-4	LAMP SOCKET ASS'Y (R)	3017903210	3017900610
5-5	INSULATION MULTI-DUCT (R) OR INSULATION CONTROL BOX	3013327900	3013328100
5-6	CONTROL SWITCH KNOB	4008Z14310	4017G31041
6	FREEZER DOOR ASS'Y	PFFT00N035	PFFT00J055
6-1	FREEZER DOOR URT ASS'Y	PFFU00N015	PFFU00J015
6-1-1	MIDDLE HINGE STOPPER	3015200900	3015200900
6-1-2	TAPPING SCREW	7112401611	7112401611
6-1-3	REFRIGERATOR HANDLE BUSHING	4010Y36211	4010Y36211