


# G2002CW

## Explosion View

### and

### Parts List



|    |  |     |                                       |
|----|--|-----|---------------------------------------|
| 52 | clamp (for cook top)                   | 79  | lower (bake) burner                   |
| 53 | switch                                 | 80  | lower (bake) burner support           |
| 54 | clamp (for glass)                      | 81  | middle separating panel               |
| 55 | inner (middle) glass                   | 82  |                                       |
| 56 | door seal (for inner glass)            | 83  |                                       |
| 57 | knob socket                            | 84  | drawer installation base              |
| 58 | spring for knob                        | 85  | adjustable foot                       |
| 59 | knob                                   | 86  |                                       |
| 60 | rubber seal for door frame             | 87  |                                       |
| 61 | inner door frame                       | 88  | oven fixing piece 1                   |
| 62 |  | 89  | oven fixing piece 2                   |
| 63 |  | 90  | decorative liner for right side panel |
| 64 | door hinge                             | 91  | right side panel                      |
| 65 | glass (for door)                       | 92  | rack                                  |
| 66 | handle connecting bracket              | 93  | baking tray                           |
| 67 | door handle                            | 94  | support for gas ext. pipe             |
| 68 | bottom door liner                      | 95  | gas extension pipe                    |
| 69 | } drawer assembly                      | 96  | gas inlet connector (adapter)         |
| 70 |  | 97  | tap (burner valve)                    |
| 71 |  | 98  | washer                                |
| 72 |  | 99  | gas inlet tube                        |
| 73 |  | 100 | bracket for gas inlet valve           |
| 74 |  | 101 | thermostat                            |
| 75 | gas connector pipe (for top burners)   | 102 | inside back panel                     |
| 76 | gas connector pipe (for oven burners)  | 103 | left hinge base                       |
| 77 | lower protective panel for inner liner | 104 | left spring                           |
| 78 | bottom panel for inner liner           | 105 | hinge base bracket                    |
|    |  | 106 |                                       |
|    |  | 107 |                                       |

|   |                          |    |                              |    |                                  |    |                           |    |                         |    |  |
|---|--------------------------|----|------------------------------|----|----------------------------------|----|---------------------------|----|-------------------------|----|--|
| 1 | right hinge stopper      | 8  | rear (inside) glass          | 15 | small rear plate                 | 22 | burner connector          | 29 | upper separating panel  | 36 | igniter clamp                          |
| 2 | right hinge upper slider | 9  | rear panel                   | 16 | rear panel                       | 23 | connector support         | 30 | burner support bracket  | 37 | igniter                                |
| 3 | right spring             | 10 | rubber seal for inside glass | 17 | rear insulation material         | 24 | nozzle                    | 31 | cook top                | 38 | small burner assy.                     |
| 4 | right hinge lower slider | 11 | left hinge base slider       | 18 | main cabinet insulation material | 25 | M12 bolt                  | 32 | right burner grate      | 39 | decorative strip (for left side panel) |
| 5 | right hinge base slider  | 12 | left hinge stopper           | 19 | igniter module                   | 26 | rear panel of inner liner | 33 | left burner grate       | 40 | left side panel                        |
| 6 | hinge axle               | 13 | power cord                   | 20 | smoke cover                      | 27 | top panel of inner liner  | 34 | medium burner assy. (2) | 41 | side panel of inner liner              |
| 7 | clamp                    | 14 | clamp for power cord         | 21 |                                  | 28 |                           | 35 | large burner assy.      | 42 | front panel of inner liner             |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 43 |  |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 44 | upper burner                           |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 45 | burner igniter                         |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 46 | upper burner fixing support            |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 47 | door hinge fixing plate                |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 48 | gasket connecting piece                |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 49 | gasket hook                            |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 50 | gasket                                 |
|   |                          |    |                              |    |                                  |    |                           |    |                         | 51 | control panel                          |