



Item no	description	qty
POW81B-1	handle	1
POW81B-2	handle seat	2
POW81B-3	door clip	1
POW81B-4	glass door	1
POW81B-5	switch knob	1
POW81B-6	decorative board	1
POW81B-7	panel	1
POW81B-8	thermostat	1
POW81B-9	bake tray	1
POW81B-10	grid	1
POW81B-11	pulley	1
POW81B-12	pivot support	1
POW81B-13	shim	1
POW81B-14	door hook	1
POW81B-15	sliding spring	1
POW81B-16	left plate	1
POW81B-17	heating element	4
POW81B-18	roof	1
POW81B-19	the top of the code	1
POW81B-20	housing	1
POW81B-21	lower door lamp	1
POW81B-22	door hinges	1
POW81B-23	small spring	1
POW81B-24	shaft sleeve	1
POW81B-25	knob decoration ring	1
POW81B-26	timer knob	1
POW81B-27	aseismatic glue	1
POW81B-28	indicator light	1
POW81B-29	function switch	1
POW81B-30	timer	1
POW81B-31	crumb tray	1
POW81B-32	bottom enclosure	1
POW81B-33	foot	4
POW81B-34	right plate	1
POW81B-35	rear enclosure	1
POW81B-36	Buckle line	1
POW81B-37	power cord	1
POW81B-38	back foot	2
POW81B-39	Non-slip mat	1
POW81B-40	tray handle	1