

## RM2411B

No.	Part No.	Description	Qty/PCS
1		Cabinet	1
2	BC48.0-4	Upper Hinge cover	1
3 & 4	BC48.0.2	Upper Hinge Assembly	1
5	BC48.0-5	Upper Hinge Paper mat	1
6	BC48.0-2	Evaporator	1
7	BC48.2.1	Foamed Door with gasket	1
8	BC70.2-1	Gasket	1
9	BC70.2-3	Door Rack Bar	1
10	BC48.0-12	Inner Freezer Door	1
11	BC48.0.6.1	Thermostat	1
12	BC48.0-7	Thermostat Knob	1
13	BC48.0-11	Thermostat Box	1
14	BC48.0-9	Water Drip Tray	1
15 & 16	BC48.0.3	Lower Hinge assembly	1
17	BC48.0-18	Adjustable Leg	1
18	BCD96.2.2.1-5	Door Limit	1
19	BC70.0-7	Upper shelf	1
20	BC70.0-11	Lower shelf	1
21	BC48.0-10	Fixed Leg	1
22	BC70.0-16	Top hole cover	2
23		Dryer	
24		Power Cord	
25 & 26	BC70.0-12	Compressor Base Assembly	1
28	BC48.0.1-1	Compressor	1
30	BC48.0.1-2	Overload Protecotor	1
31	BC48.0.1-3	PTC Starter	1
32	BC48.0.1-4	Compressor Relay Cover	1
34 & 35	BC48.10-3	Box for Wire connection	1

