



BC-130(RM4401W/RM4402B/RM4489SS) EXPLODED VIEWS



BC-130(RM4401W/RM4402B/RM4489SS) EXPLODED VIEWS



(RM4401W/RM4402B/RM4489SS)

PART LIST

NO	Parts Number	PART NAME	QTY
1	BC130.2b/W	Foamed Door/RM4401W	1
	BC130.2b/B	Foamed Door/RM4402B	1
	BC130.2b/S	Foamed Door/RM4489SS	1
2	BC48.2-1/BC130	Gasket	1
3	BC126.1.2-2b	Cabinet	1
4	BC48.0-4	Upper Hinge cover	1
5		Self Tapping Screw	2
6	BC48.0.2	Upper Hinge	1
7	BC48.0-5	Paper Washer	1
8	BC48.0-11	Thermostat Box	1
9	BC130.0-9	Thermostat	1
10	BC48.0-7	Thermostat Knob	1
11	BC130.0-20	Bottle Bar	2
12	BC130.0-17a	Curved Soda Can Rack	1
	BC130.0-17b	Flat Soda Can Rack	1
13	BC126.0-6	Freezer Door block	2
14		Screw	4
15	BC126.0.3-1b	Freezer Door	1
16	BC126.0.4	Separated board	1
17	BC126.0.4-3	Board blocks	1
18	BC130.0-5	Shelf	1
19	BC70.0-10	Evaporator Plate	1
20	BC70.0.2	Under Hinge	1
21		Self Tapping Screw	3
22	BC48.0-18	Adjustable Foot	1
23	BC48.0-10	Fixed Leg	1
24	BC48.0.5	Power Supply Cord	1
25	BC48.0-13	Terminal Box	1
26		Self Tapping Screw	2
27	BC48.0.4	Drier	1
28		Self Tapping Screw	4
29	BC130.0-2	Compressor Base	1
30	BC130.0.30	Compressor	1
31	BC130.0.30/1	Overload Protec	1
32	BC130.0.30/2	PTC Starter	1
33	BC130.0.30/3	Relay Cover	1
34	BC130.0.30/4	Relay Band	1
35		Screw	2
36		Button	2
37		Screw	1
38	BC48.0-19	Main Wire Fixation	1
39		Bolt	4
40		Small Button	2