

	Parts No.	Parts Name	QTY
1	B153.3/U	Upper Door Gasket	1
2	B153.2/U	Upper Glass door	1
3	B130.3-1	Lock	1
4	B153.2/L	Lower Glass Door	1
5	B153.3/L	Lower Door Gasket	1
6	B130.0-1	Shelf	5
7	B107. 15-5	Lamp Holder	1
8	B107.15-2	Lamp House	1
9	B103.3-2	Lock Block	1
10	B107.15-1	Lamp House Holder	1
11	B130.0-3A	Bottom Rack	1
12	B107.6.2	Bottom Hinge	1
13	B107.6.1-2	Adjustable Leg	1
14	B145. 20	Thermostat Sensor	2
15	B102.5.1-1	Fix Leg	1
16	B107.10	Power Supply Cord	1
17	B106	Evaporator Tray	1
18	B103.0-2	Button	2
19	B153.1	Cabinet	1
20	B102.5.1-2	Compressor Bracket	1
21	B153.5	Electronics temperature	1
22	B153.4-1	Grommet	4
23	B153.4-2	Tube	4
24		Self-tapping Screw	4
25	B153.4-0	Compressor	1
26	B153.4-3	PTC Starter	1
27	B153.4-4	Overload Protector	1
28	B153.4-5	Relay Cover	1
29	B153.4-6	Clip for Relay Cover	1
30	B153.0-4	Eletromagnetic Valve	1
31	B153.0-11	Temperature Sensor Cove	2
32	B153.0-1	Middle hinger	1
33	B153.0-14	Top hinger	1
34	B153.1-2	Counter top foam	1
35	B153.1-1	Counter top	1
36	B153.1-3	Service Tray	1
37	B153. 6-1	Electronic Control	1
38	B153. 6-2	Electronic Control Panel	1
39	B130. 0-7	Top Cover Plate	1

BC-82WC<DIGITAL> PARTS BLEAKDOWN

