



WC52SS Part List

No.	Part Name	Qty
1	Wire Shelf II	1
2	Wire Shelf I	5
3	Bottom Hinge Plug	1
4	Philips Flat Head Self Drilling Screw	2
5	Door Handle Bar	1
6	Glass Door Assy	1
7	Top Hinge Plug	1
8	Door Gasket	1
9	Reflecting Plate	1
10	Bulb Nip	1
11	Bulb	1
12	Temp Control Circuit Board	1
13	Button Plate	1
14	Display Circuit Board	1
15	Light Cover	1
16	Thermostat Socket	1
17	Display Panel	1
18	Cabinet Foamed Assy	1
19	Adjustable Leg	2
20	Philips Hex Wahser Head Self Drilling Screw	8
21	Bottom Hinge	1
22	Wind Baffle	1
23	Cover Board	1
24	Top Hinge Cover	1
25	Philips Flat Head Self Drilling Screw	6
26	Top Hinge	1
27	Back Cover	1
28	Condensator	1
29	Clapboard	1
30	Fan	1
31	Fan Bracket -1	1
32	Shockproof Loop	1
33	Motor Assy	1
34	Fan Bracket -2	1
35	Philips Flat Head Self Drilling Screw	22
36	Electric Box Socket	1
37	Electric Box Cover	1
38	Power Cord Assy	1
39	Vaporizing Case	1
40	Compressor	1
41	Hex Wahser Head Self Drilling Screw	4
42	Compressor Absorber Rubber	4
43	Capacitance	1
44	Cable Fixing Nip	1
45	Compressor Support Plate	1