



**VFR14PS-IS PARTS LIST**

Number	Code	Name	Quantity
1	BD40.1	Cabinet	1
2	BC70.2-5	Rivet	2
3	BC48.0-4	Top hinge cover	1
4	BC48.11	M5*12 screw	2
5	BC48.0.2	Top hinge	1
6	BC48.0-5	Top hinge plate	1
7	BC48.0-10	Fixed leg	1
8	BC70.0-17	Adjustable leg	1
9	BC70.0.2	Bottom hinge	1
10	BC48.11	ST5*14 screw	2
11	BD40.0-3	Wire shelf	1
12	BD40.0-2	Water plate	1
13	BD40.0-4	Thermostat knob	1
14	BD40.0-1	Thermostat	1
15	BC48.11	ST4*10 screw	2
16	BD40.0-5	Thermostat cover	1
17	BC48.0.4	Drier	1
18	BC48.0.5	Power cord	1
19	BC70.0-12	Compressor base	1
20	BC48	ST5*14 screw	4
21		Grommet	4
22	B25H5	Compressor	1
23		Bushing	4
24		Overload protector	1
25		PTC Starter	1
26		Relay cover	1
27		Relay band	1
28	BD40.2-1	Door	1