




MODEL HRS88N1B  
SECURITY SAFE  
INSTALLATION AND USAGE INSTRUCTIONS

Your Avanti Room Security Safe is supplied with the following:

1 – Security Safe Unit	4 – 1.5V Batteries	4 – Rubber Feet
2 – Emergency Access Keys	1 – Felt Liner	
1 – Installation / Usage Guide	Installation Screws	




### INSTALLING YOUR SECURITY SAFE

When installing your safe, be sure the location is sturdy enough to support the unit and is both secure and easy to access.

Safe can be installed onto either a concrete or wooden surface.

When installing use a 25/64" (10mm) drill bit and screws.

To prevent removal of your security safe, it is recommended to use Allen type screws (not included) to affix the unit to the installation location.



## INITIAL SETUP AND CONFIGURATION.

After you have installed the unit in its final location, proceed to set up digital access controls.

- 1) Using the emergency Access Key, open the safe.
- 2) Open the battery compartment cover.
- 3) Following the image shown in the battery compartment install 4 AA sized batteries.
- 4) Close the battery compartment cover.
- 5) The words "ALL READY" will be displayed on the LCD display for approximately 1 second; the security safe will then go into "STANDBY Mode".
- 6) Once in "STANDBY Mode" the LCD display will show the date and time (YY, MM, DD).
- 7) Using the keypad, enter the initial setup password "1234" or the administrator password "8888".

### NOTE:

**Battery Life / Level indicator:** The battery indicator on the LCD display will show the current status of the batteries. Always replace all of the batteries at the same time. If at any time the battery level is too low to operate the security safe, use the emergency access key.

**Safety / Security Feature:** If the passcode is entered incorrectly more than 3 times the keypad will go into lock mode. After approximately (5) five minutes the keypad will return to normal working function.

**Interior Light:** When the safe is unlocked using the keypad, the interior light will turn on and will turn off automatically after approximately 45 seconds.

**Automatic Door Opening:** When the safe is unlocked using the keypad the door will automatically open slightly outward to allow easy / quick access to contents stored in the safe.

## GUEST / USER CODE SETUP

To reset the access code read and follow the steps below.

- 1) With the door open, enter a new 4 – 8 digit code and press the "#" key to confirm the new pass code.
- 2) You will hear and see the security lock engage and the word "CLOSE" will be displayed on the LCD screen.
- 3) Enter the new pass code and press the "#" key again to open the security safe. The security lock will disengage and the word "OPEN" will be displayed on the LCD screen.
- 4) Close the door and enter the new code set up in step # 1 and press the "#" key. The word "CLOSE" will be displayed on the LCD screen and the security lock will engage.
- 5) If the Guest / User enters the wrong pass code three (3) times in a row the keypad will go into security-lock mode and will remain locked for approximately (5) five minutes. After the (5) five minutes has elapsed the keypad will return to normal operation.

## RESETTING THE ADMINISTRATOR PASSWORD

To reset the access code read and follow the steps below.

- 1) With the door open, press the "#" key to activate the keypad, then press the "0" key twice, then press the "red" button on the battery compartment once to enter the programming mode.
- 2) Once in the programming mode you will hear a "DI" sound and "- - -" will be shown in the LCD display.
- 3) Enter the new 4 – 8 administrator password and press the "#" key to confirm.
- 4) The word "INTO" will show on the LCD display to confirm the new password has been set successfully.



Avanti Products  
Miami, FL 33172

In the event of service issues, please call the  
Customer Hotline at 1-800 – 220 - 5570

Additional Instructions:

Manual Operation (Open using the key).

- User will need to remove the key hole cover by placing a small pin or similar object in the hole below the keyhole and key hole cover.
- Insert the emergency access key into the lock and turn clockwise to open the safe.
- While the door is open, change the batteries on the control panel or reset the passcode as described in the “Resetting the Administrator Password” section.


Setting the Date, Time and Weekday:

- After the batteries have been installed, the LCD display will show “00-01-01” (Year-Month-Date) and “Week 1” (Monday) “00-00” (Time).
- Press the “\*” to enter the programming mode, the “00” will begin to flash.
- Increase by pressing the “ 8 “ or Decrease by pressing the “ 0 “, when finished press the “#” to move to the next item.

When finished programming, do not touch any key for approximately 7 seconds and the program will take effect.

Tips:

For your convenience four (4) rubber feet are included with each safe and can be installed if needed.



Displaying the Audit Trail

1. Open the safe with the correct Administrator Password, after “open” displays on the LCD and vanishes, press “8” to go backwards or “0” to go forward when the blue LCD background light is still on.
2. The LCD will display the current opening record with the following content: No 001 (opening count)
3. Pass 1 (personal password)
4. Pass 2 (administrator password)
5. The year – month- date time and day of the week when the safe was opened.
6. Press “0” before the displayed record disappears to move forward to the next record.

**Avanti**<sup>®</sup>

Avanti Products  
Miami, FL 33172  
In the event of service issues, please call the  
Customer Hotline at 1-800 – 220 - 5570

<p align="center"><b>YOUR AVANTI PRODUCTS WARRANTY</b></p>	<p>Staple your sales receipt here. Proof of original purchase date is needed to obtain service under warranty.</p>
<p><b>WHAT IS COVERED – LIMITED ONE-YEAR WARRANTY</b></p>	
<p>Avanti Products warrants that the product is free from defects in materials and/or workmanship for a period of twelve (12) months from the date of purchase by the original owner. The foregoing timeline begins to run upon the date of purchase, and shall not be stalled, tolled, extended, or suspended for any reason whatsoever unless described in detail in the warranty document. For one year from the date of purchase by the original owner, Avanti products will, at its option, repair or replace any part of the product which proves to be defective in material or workmanship under normal use. Avanti Products will provide you with a reasonably similar product that is either new or factory refurbished. During this period Avanti Products will provide all parts and labor necessary to correct such defects free of charge, so long as the product has been installed and operated in accordance with the written instructions in this manual. In rental or commercial use, the warranty period is 90 days. All Avanti Products of 4.2 cubic feet capacity or less must be brought / sent to an authorized appliance service center for repair.</p>	
<p align="center"><b>THIS WARRANTY DOES NOT APPLY OUTSIDE THE CONTINENTAL UNITED STATES OF AMERICA.</b></p>	
<p><b>WARRANTY EXCLUSIONS / WHAT IS NOT COVERED:</b></p>	
<p><b>The warranty coverage described herein excludes all defects or damage that are not the direct fault of Avanti Products, including without limitation, one or more of the following:</b></p>	
<ul style="list-style-type: none"> <li>• A failure to comply with any applicable state, local, city, or county electrical, plumbing and/or building codes, regulations, or laws, including failure to install the product in strict conformity with local fire and building codes and regulations.</li> <li>• Any external, elemental and/or environmental forces and factors, including without limitation, rain, wind, sand, floods, fires, mud slides, freezing temperatures, excessive moisture or extended exposure to humidity, lightning, power surges, structural failures surrounding the appliance, and acts of God.</li> <li>• Damage, deterioration or malfunction resulting from:             <ol style="list-style-type: none"> <li>1) Accident, negligence, misuse, abuse, improper installation, failure to perform normal maintenance or operation to follow instructions labeled on or provided in the safe.</li> <li>2) Any unit which has been altered or on which the serial number has been defaced, modified or removed.</li> <li>3) Normal wear, battery replacement, any periodic maintenance or where combination lock has been changed without factory authorization.</li> </ol> </li> </ul>	
<ul style="list-style-type: none"> <li>• Installation or removal charges.</li> <li>• Shipping and handling costs associated with the replacement of the unit.</li> <li>• State sales tax does not apply to warranty service work and will not be honored.</li> <li>• Repairs performed by unauthorized servicers.</li> <li>• Service calls that are related to external problems, such as abuse, misuse, inadequate electrical power, accidents, fire, floods, or any other acts of God.</li> </ul>	<ul style="list-style-type: none"> <li>• Failure of the product if it is used for other than it intended purpose.</li> <li>• Surcharges including but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas.</li> <li>• Damages based on inconvenience, loss of use, damage or loss of contents, or any other damages whether incidental, consequential or otherwise.</li> </ul>
<p>In no event shall Avanti Products have any liability or responsibility whatsoever for damage to surrounding property, including cabinetry, floors, ceilings, and other structures and/or objects around the product. Also excluded from this warranty are scratches, nicks, minor dents, and other cosmetic damages on external surfaces and exposed parts; Products on which the serial numbers have been altered, defaced or removed; service visits for customer education, or visits where there is nothing wrong with the product; correction of installation problems (you are solely responsible for any structure and setting for the product, including all electrical, plumbing and/or other connecting facilities, for proper foundation/flooring, and for any alterations including without limitation cabinetry, walls, floors, shelving etc., as well as the resetting of breakers or fuses.</p>	
<p><b>OUT OF WARRANTY PRODUCT</b></p>	
<p>Avanti Products is under no obligation, at law or otherwise, to provide you with any concessions, including repairs, pro-rates, or product replacement, once this warranty has expired.</p>	
<p><b>HOW TO OBTAIN WARRANTY SERVICE</b></p>	
<ol style="list-style-type: none"> <li>1) If your Avanti product requires service, contact our Service department 1-800-220-5570 or contact your local authorized Avanti service center.</li> <li>2) Upon contact with the Service department or an authorized service center you will be advised on the necessary procedure to follow.</li> <li>3) All warranty service MUST have prior authorization, accompanied by proof of purchase as evidence of warranty coverage. A warranty authorization MUST be obtained from Avanti Products before any service is performed.</li> <li>4) Only authorized service representatives may perform warranty service. Any service performed prior to issuance of a warranty authorization number will be subject to denial.</li> </ol>	
<p>HRS88N1B 03202018</p>	<p align="right">WARRANTY – Room Safes PRINTED IN CHINA</p>